

MINI1300Antennaanalyzer



一、 Specification:

FrequencyRange:0.1-1300 MHZ HF VHF/UHF continuous coverage, HF NHF/UHF FM
0.1-1300M HF VHF/UHF

In/Out Impedance:50

Measurement Parameters:SWR, R, +Jx, -Jx, IZI, Return loss

Measurement Mode:Single point measurement, Scanning Frequency Sweep), and
TDRMode

SWRMeasureMentRange:1.0-1999(Single Point Mode),1.0-20.0(ScanMode)

DisplaynModes:Numerical display,curve display,smith chart

ConnectorType:UHF N-type connector

VAN:SMA

SMA OPEN-SHORT-LOAD Calibration Kitx1

LCD size:480x2724.3" TFT LCD display

Touch Screen Type:Capacitive All capacitive touch screen on the display-
no button needed

PowerSource:USB or Internal Li-ion

Built-in Li-ion charging circuitry and DC-DC booster

Maximum charging current-5V/1.5A

External Storage Method:TF card

Dimensions:133 • 85 • 29mm Does not contain prominent ports.


Weight:550g

Warning: if the product has parameter changes, the actual test will prevail.


Package Included:

1-2019 New 0.1-1300 mhz HF NHF/UHF AntennaAnalyzer Capacitive Touch Screen

Port specification



Main menu



- | | | |
|-----|-------------------|--------------|
| 1. | single Frequency | 单频点测试 |
| 2. | Frequency sweep | 频率扫描 |
| 3. | multi swr | 多波段驻波测试 |
| 4. | tune swr | 单频率驻波测试 |
| 5. | S21 gain | S21 增益测试 |
| 1: | 6. find Frequency | 频谱仪 |
| 7. | quartz data | 晶振测试 |
| 8. | TDR mode | 馈线长度测试 |
| 9. | L/C meter | 电感电容表 |
| 10. | DSP | 测量板输入端的噪声和电平 |
| 11. | configuration | 系统配置菜单 |
| 12. | manage snapshot | 照片管理 |
| 13. | USB HS Reader | USB 读卡 |
| 14. | RF generator | 信号发生器 |
| 15. | WSPR/FT8/JT65 | (V3.5 未启用) |

changed step wise.


Set Frequency leads to the frequency selection window base in Panoramic scan

The outline area with the SWR display also includes the values connection of the measured impedance.

Touching this area switches to the equivalent parallel circuit

Tapping the Smith chart shows the dimensioning of the 2 possible LC matching networks in order to transform the measured impedance to 50


2. Frequency sweep



Frequency Sweep (Panorama-Frequene scan)

Mit dem Antippen des oberen Bildschirmrands öffnet sich das Fenster zur Frequenzeingabe. Wahlweise kann ein Amateurband ausgewählt oder die Mittenfrequenz sowie die Bandbreite frei gewählt werden:

3. multi swr




Changing or adding positions: tapping the frequency respectively of an empty field.

Delete a location: Touch-frequency field and in the frequency menu Cancel choose

The selected frequencies are stored.

Tune swr



SWR-Messung ändern sich Farbe und Länge eines Streifens. Wenn das mit SWR_2 respektive SWR_3 gewählte Ziel-SWR unterschritten wird ist der Balken weiss und grün. Wird das gewählte Ziel-SWR überschritten ist der Balken weiss und rot. Die Frequenz des Tons variiert mit dem SWR: Je kleiner das SWR, desto

tiefer der Ton. Tone schaltet den Ton
ein, Mute schaltet ihn aus.

SWR

5. S21 gain

S21

1. Feeder connection VNA and ANT ports




2.

Open the Calibration Menu
(S21)Gain Calibration for VNA




3.

Filter test



6. find Frequency




Automatic: Continuous scan on/off

Frequency : Choice of frequency and scanning

Test : 3.5 MHz generator on/off

Spectrum : Spectrum display on/off

7. quartz data



Nach Eingabe der Frequenz wird mit Calibrate OPEN die parasitäre Impedanz des Anschlusses gemessen. Danach wird der Benutzer aufgefordert, den Quarz in den Sockel zu stecken und mit Start die Messung

8. TDR mode



Cable Length

To determine the electrical length of cables or to locate cable faults. The cursor is automatically at the point of maximum discontinuity. The velocity factor can with CHF. Vf be changed. Store volatile stores it only for current measurements, Store permanently however.

9. L/C meter




Calibration before use: short , 50 ohms, open

10. DSP

Noise and Level at Input of Measuring Board



11. configuration



11.1 Color settings

11.2 System settings

11.3 Calibration menu

A: ANT 5.1R, 50R , 300R,

ANT antenna test port calibration, respectively access 5.1R, 50R, 300R, three false loads

B:

Calibration of Internal Inspection Board (No Use)

C:

VNA calibration, feeder short circuit ANT and VNA port calibration

D:

Maximum oscillation test

11.4 DSP Noise and level of input of DSP measuring board

11.5 Battery Voltage Calibration

Have been calibrated, please do not change the parameters.

11.6 Clock setting


Set year, month, day, time

11.7 Photo management snapshot

You can view photos kept in SD memory


11.8 USB memory

Connect to the computer to view the memory




12. manage snapshot

You can view photos kept in SD memory



13. USB HS Reader USB



14. RF generator Generator AM/FM



AM modulates the carrier at 500 Hz

AM

FM causes a frequency shift of ± 150 Hz with

15. WSPR/FT8/JT65

(V1.0, V3.5)