

# Manual Straight Key (VK-5) Instructions


## Instructions:

### 1. Methods of adjusting the feel:

#### 1.1 Adjust the tightness of the spring:

Rotate ① the high-head thumb nut and at the same time with the press.


② After finding a suitable spring tension, tighten it. ③ Keep the round thumb screw in its same state.



#### 1.2 Adjust the distance between firing pin contacts:

1) Adjust the distance between contact 1 and contact 2 by rotating the contact screw.

2) The straight knurling thin nut should be pressed against the contact bracket and tightened. Then, secure the contact screw (maintaining the contact distance).



## 2. Connector Instruction:

Plug model: 3-core 3.5mm plug

