

IC-705 Battery Icon Addendum

Version 1.11 Firmware adds the color red for the battery icon when the battery is nearly discharged. This color represents a fourth level of discharge. Previously, there were three levels of discharge shown in the icon and they were all green. The original versions of the Basic and Advanced Instruction manuals describe just the green indicators present (from firmware v1.0).

■ Battery icon

A red battery icon  is added.

Old Version:  →  →  (green) → Blinks

New Version:  →  →  (green) →  (red) → Blinks

- ⓘ Immediately charge the battery pack when the red battery icon is displayed. Otherwise, the icon will soon start blinking, "LOW BATTERY" will be displayed, and the transceiver will automatically turn OFF.