


TS-520S



- 3SK22 (Y) or (GR)
- 2SK19 (Y) (GR)
- 2SC460 (B)
2SC458 (B)
2SC1515 (K)
- 2SC372
2SC373
2SC735
2SA495 (Y)
2SC733 (Y)
2SC734 (Y)
2SC1000 (GR)
2SA562 (Y)
- 3SK41 (L)
3SK35 (GR)
3SK35 (Y)
- 2SK30 (O)
- 2SC945 (R)
- 2SB481 (I, J)
2SD90 (Y) or (G)
- 2SA606