




BLOCK DIAGRAM




PICTORIAL 6-3




Detail 6-3C








PICTORIAL 7-3




PICTORIAL 7-4




PICTORIAL 8-1




PICTORIAL 8-2




PICTORIAL 8-3




PICTORIAL 8-4




PICTORIAL 8-5




PICTORIAL 8-6




PICTORIAL 11-1




Detail 11-1D




PICTORIAL 11-4




PICTORIAL 11-5




PICTORIAL 11-6




Detail 11-7A




Detail 11-7B



PICTORIAL 12-10




PICTORIAL 13-1




BLUE AND WHITE LABEL


PICTORIAL 13-2




PICTORIAL 13-3




PICTORIAL 13-4




PICTORIAL 13-5




PICTORIAL 13-6




PICTORIAL 14-4




PICTORIAL 14-6




PICTORIAL 14-8



PICTORIAL 14-10



PICTORIAL 14-9




PICTORIAL 16-2


CIRCUIT BOARD X-RAY VIEWS

NOTE: To find the PART NUMBER of a component for the purpose of ordering a replacement part:

- Find the circuit component number (R1, C1, etc.) on the "X-Ray Views."
- Locate this same number in the "Circuit Component Number" column of the appropriate "Parts List."
- Adjacent to the circuit component number, you will find the PART NUMBER and DESCRIPTION which must be supplied when you order a replacement part.




DRIVER CIRCUIT BOARD
(Shown from the component side)




OUTPUT FILTER CIRCUIT BOARD
(Shown from the component side)


* NOTE: L609 is mounted on spacers, above the surface of the board.



ANTENNA SWITCH CIRCUIT BOARD
(Shown from the component side)



POWER SUPPLY CIRCUIT BOARD
(Shown from the component side)



VFO CIRCUIT BOARD
(Shown from the component side)