

**General:** Your CTX-10 transceiver leaves the factory with the most current firmware loaded. When powering-up the CTX-10, the firmware revision is indicated by the 4-digit number on the lower-left of the screen. (The lower right side indicates the serial number.)

When new firmware is available, an email is sent to all registered owners indicating the new revision number with an explanation of the changes made. The email will indicate the Dropbox link to download the latest firmware revision and documentation.

The CommRadio store ([www.commradio.com](http://www.commradio.com)) also provides the latest revision number and the Dropbox link:

[https://www.dropbox.com/sh/o52isgpavqz2org/AACRWiWTE5wNPN9pwO\\_PeMKYa?dl=0](https://www.dropbox.com/sh/o52isgpavqz2org/AACRWiWTE5wNPN9pwO_PeMKYa?dl=0)

Download all files shown on this Dropbox page to a folder on your Desktop (Windows).  
Rename as necessary for your convenience: CTX-10

**The required files are (stored in same folder on your PC):**

1. CTX10Updater.exe (PC GUI program)
2. ftd2xx.dll (Required by internal FTDI USB IC)
3. ctx10-1008.pkg (the firmware image used by the CTX10Updater GUI)

Other files such as these instructions, the latest revision of the User-Manual and any Newsletters, are optional.

**Instructions: (CTX-10 powered-down):**

1. **Connect a USB cable (mini-A furnished) to your PC.**
2. **Start the CTX10Updater GUI.**
3. **Power-up the CTX-10.**
4. **The window in lower left will turn green and indicate: *connected*.**
5. **Click: *Update Software***
6. **Select (open) the latest firmware file in the pop-up window: *ctx-10-1008.pkg***

The top of 4 progress bars will indicate progress in green. Be patient and wait (5-7 minutes) until all 4 bars are 100% green. Do not touch any controls on the CTX-10 during the process.

7. **Power-down.**
8. **Unplug USB Cable and close the CTX10Updater GUI.**
9. **Power-up and observe the corresponding version number on lower left side of the CTX-10 Welcome Screen**