




Connecting power supply




Connecting PTT & Mic



Connecting speaker & volume reg.




Power & control for peripheral equipment




Connecting the Paddle and Stright key

(when stright - use only red wire)




GROUND DOT DASH

RF connections




Connecting encoder

OPTICAL ENCODER



MECHANICAL ENCODER




Connecting peripheral equipment







Mini jack 3,5mm stereo




Mini jack 3,5mm stereo




Mini jack 3,5mm stereo




Connecting s-meter and power meter



COMPRESSION UNIT



SETTING BFO



LSB 11998,500 -1,500 = 11997,000



USB 11998,500 +1,500 = 12000,000