


RCA SENIOR VOLTOHMYST®

ELECTRONIC METER

Type WV-97A

- Specifications
- Operation
- Applications
- Maintenance



RADIO CORPORATION of AMERICA
 TEST AND MEASURING EQUIPMENT
 HARRISON, N. J.

Safety Precautions

The metal case of this instrument is connected to the ground of the internal circuit. For proper operation, the ground terminal of the instrument should always be connected to the ground of the equipment under test. The WG-218 Direct Probe and Cable has a shield throughout its entire length which is connected to the instrument ground and case. Always handle the WG-218 by the insulated probe housing.

An important point to remember is that there is always danger inherent in testing electrical equipment which operates at hazardous voltages. Therefore, the operator should thoroughly familiarize himself with the equipment under test before working on it, bearing in mind that high voltages may appear at unexpected points in defective equipment. Additional precautions which experience in the industry has shown to be important are listed below.

1. It is good practice to remove power before connecting test leads to high-voltage points. If this is impractical, be *especially careful* to avoid accidental contact with equipment racks and other objects which

can provide a ground. Working with one hand in your pocket and standing on a properly insulated floor lessens the danger of shock.

2. Filter capacitors may store a charge large enough to be hazardous. Therefore, discharge filter capacitors before attaching test leads.

3. Remember that leads with broken insulation provide the additional hazard of high voltages appearing at exposed points along the leads. Check test leads for frayed or broken insulation before working with them.

4. To lessen the danger of accidental shock, disconnect test leads immediately after test is completed.

5. Remember that the risk of severe shock is only one of the possible hazards. Even a minor shock can place the operator in hazard of more serious risks such as a bad fall or contact with a source of higher voltage.

6. The experienced operator continuously guards against injury and does not work on hazardous circuits unless another person is available to assist in case of accident.

ITEMS


Supplied with WV-97A:

- | | |
|--|------------------------|
| 1 Direct Probe and Cable..... | Type No. WG-218 |
| 1 DC Probe | Type No. WG-217 |
| 1 Ohms Cable, with probe..... | Stock No. 51960 |
| 1 Ground Cable, with alligator clip..... | Stock No. 48996 |
| 1 Slip-On Alligator Clip..... | Stock No. 59410 |
| 1 1.5-Volt Battery..... | Type No. VS036 |
| 1 RCA-12AU7 Tube | 1 Warranty Certificate |
| 2 RCA-6AL5 Tubes | 1 Instruction Booklet |

ACCESSORIES

Available on Separate Order:

- For Measuring AC Voltages at Frequencies from 50 Kc to 250Mc:
 Crystal Probe Type No. WG-264
- For Increasing DC Voltage Range to 50,000 Volts:
 High-Voltage Probe Type No. WG-289
 Multiplier Resistor Type No. WG-206



Cables and Probes supplied with the WV-97A

Devices or arrangements shown or described herein may use patents of RCA or others. Information contained herein is furnished without responsibility by RCA for its use and without prejudice to RCA's patent rights.



SENIOR VOLTOHMYST TYPE WV-97A

The following changes should be made in the WV-97A Instruction Booklet, Instr. WV-97A (4).

Page 9, left-hand column, third line, change to read as follows:

6. Read the ac voltage from the scale corresponding to the range-selector setting.

Page 9, right-hand column, fourth line, change "Fig. 8" to read, "Figure 7."

Page 15, under subhead "Meter Response," change 0.47 μ f in last line to read, "0.047 μ f."

Page 14, under Replacement Parts List, correct the listing of the cables, pin plugs, ohms jacks, and ground jacks to agree with the table below.

Changes in these components were made on all instruments with serial numbers above 10,500 (includes all instruments except those with code numbers 350 and 850) in order to utilize popular-size phone-tip plugs and jacks. The new plugs have smaller pins and the jacks have smaller holes than those used on instruments with code numbers 350 and 850.

When ordering these parts, determine the code number of the instrument and select the correct stock number from the table below to insure proper fit of parts.

Description	Stock Number	
	For Code Nos. 350 & 850	For All Other Code Nos.
Cable, Ohms, with probe and pin plug	51960	93859
Cable, Ground, with alligator clip and pin plug	48996	93832
Jack, Ohms or Ground	55239	93856
Pin plug, black, for ground cable	47089	93856
Pin plug, red, for Ohms cable	47089*	93857

* For Code Nos. 350 & 850, red plug is not available. Order black plug, Stock Number 47089.



SENIOR VOLTOHMYST


Type WV-97A

Contents

	<i>Page</i>
Safety Precautions	2
Accessories	2
List of Illustrations	4
General Description	5
Specifications	5
Function of Controls	6
Operation and Applications	7
Preliminary Adjustments	7
DC Voltage Measurements	7
Zero-Center Indication	7
Resistance Measurements	7
Measurements of Resistance Values Above 1000 Megohms	8
AC Voltage Measurements	8
Special Applications	10
Oscillator Grid-Bias Measurement	10
AVC Voltage Measurement	10
Output Indication	10
Bias-Cell Voltage Measurements	10
Detection of Gassy Tubes	10
Insulation-Resistance Measurements	10
DBM Measurements	10
Accessories	11
Schematic Diagram	12 & 13
Replacement Parts List	14
Maintenance	11
Zero Adjustment of Pointer	11
Calibration	15
AC Compensation Adjustment	15

List of Illustrations

Figure		Page
1	Chart for conversion of rms voltage to dbm values	4
2	Circuit for measurement of resistance values above 1000 megohms	8
3	Typical voltage waveforms	8
4	Details of WV-97A scales	9
5	Typical TV voltage waveforms	9
6	Voltage waveforms	9
7	Pulse response capability of WV-97A	10
8	Accessories available on separate order for use with WV-97A	11
9A	Schematic diagram	12
9B	Schematic diagram	13
10	Calibration control locations	15



92CS-7130

Note: For loads other than 600 ohms, see table on page 11.

Figure 1. Chart for conversion of rms voltage to dbm values.

General Description

Especially designed for use as a television signal tracer, the RCA WV-97A Senior VoltOhmyst* features a circuit which measures peak-to-peak voltages for both sine waves and complex waves. In addition, the WV-97A reads dc voltages, resistance values, and rms voltage values of sine waves.

The WV-97A has the high input resistance of 11 megohms on all dc ranges and is frequency-compensated for ac voltage ranges up to and including the 500-volt range. (500 v. rms or 1400 v. p-p). The frequency range of the instrument, depending on the impedance of the voltage source, is flat to approximately 3 megacycles. When the auxiliary WG-264 Crystal Probe is used, the voltage ranges are accurate to within $\pm 10\%$ from 50 kc to 250 Mc.

The Senior VoltOhmyst features a circuit which measures the peak-to-peak voltages of the complex waveshapes found in modern television receivers and industrial equipment. Since the meter reading is proportional to the peak-to-peak value of the waveshape measured, negligible waveform error is introduced in the measurement, as may be the case with meters having readings proportional to either the positive or the negative peak of the waveshape.

The RCA Senior VoltOhmyst utilizes a push-pull amplifier-type of dc bridge circuit which affords excellent linearity of response, good stability, and very high input impedance. (See Schematic Diagram, tube

V3 and associated network.) When no measurement is being made, the cathode currents through the triode units are equal. When a measurement is being made, a voltage is applied to the grid of triode unit #1 to provide a change in the cathode current of this triode unit. Since resistor R20 functions as a cathode-coupling element, the change in cathode current through R20 alters the grid-to-cathode potential of triode unit #2, a condition which modifies the cathode current of triode unit #2. When, for example, the current flow through triode unit #1 increases, the flow of current through triode unit #2 decreases. The meter reading is proportional to the difference between the plate currents of the triodes.

Additional features of the WV-97A include provision for zero-center indication, useful in discriminator and bias measurements; separate scales for low ac voltage measurements; a circuit design which allows measurements of the ac component of a signal when the dc component is present and vice versa; a separate dc probe with a 1-megohm resistor which minimizes capacitance-loading effects; and electronic protection against meter burn-out.

The RCA WV-97A Senior VoltOhmyst is a lightweight, compact, and versatile instrument. A reliable measuring device, it will prove extremely useful in television applications as well as in many industrial applications.

*Trade Mark "VoltOhmyst" Reg. U. S. Pat. Off.

Specifications

Electrical

DC Voltmeter:

Ranges.....0 to 1.5, 5, 15, 50, 150, 500, 1500 volts
 Input Resistance (With DC Probe WG-217 attached to Direct Probe & Cable WG-218):
 All Ranges.....11 megohms
 Sensitivity on 1.5-V Range.....7.3 megohms/volt
 Overall Accuracy..... $\pm 3\%$ of full scale

AC Voltmeter: (For instruments with code numbers 350.)

Ranges:

RMS Values of Sine Waves..... $\left\{ \begin{array}{l} 0 \text{ to } 1.5 \text{ volts on} \\ \text{separate LO-AC scale} \\ 0 \text{ to } 5, 15, 50, 150, \\ 500, 1200 \text{ volts}\Delta \end{array} \right.$

Peak to Peak Values of Sine Waves & Complex Waves..... $\left\{ \begin{array}{l} 0 \text{ to } 4 \text{ volts on} \\ \text{separate LO-AC scale} \\ 0 \text{ to } 14, 42, 140, 420, \\ 1400, 3400 \text{ volts}\Delta \end{array} \right.$

Overall Accuracy..... $\pm 5\%$ of full scale

Input Resistance and Capacitance

(With Direct Probe & Cable WG-218):

1.5, 5, 50, 150-V Ranges..... 0.83 meg. shunted by 70 μmf
 500-V Range..... 1.3 meg. shunted by 60 μmf
 1200-V Range..... 1.5 meg. shunted by 60 μmf

Frequency Response:

With Direct Probe & Cable WG-218* $\left\{ \begin{array}{l} 30 \text{ cps to } 3 \text{ Mc}\square \\ 30 \text{ cps to } 500 \text{ kc}\Delta \\ 30 \text{ cps to } 270 \text{ kc}\circ \\ 30 \text{ cps to } 80 \text{ kc}\diamond \end{array} \right.$

With Crystal Probe WG-264*..... $\left\{ \begin{array}{l} \text{within } \pm 10\% \text{ from} \\ 50 \text{ kc to } 250 \text{ Mc} \end{array} \right.$

Pulse Response Capability..... See Fig. 7

Δ CAUTION: See Maximum Input Voltages.

AC Voltmeter: (For instruments with all code numbers except 350.)

Ranges:

RMS Values of Sine Waves..... $\left\{ \begin{array}{l} 0 \text{ to } 1.5 \text{ volts on} \\ \text{separate LO-AC scal.} \\ 0 \text{ to } 5, 15, 50, 150, \\ 500, 1500 \text{ volts} \end{array} \right.$

Peak to Peak Values of Sine Waves & Complex Waves..... $\left\{ \begin{array}{l} 0 \text{ to } 4 \text{ volts on} \\ \text{separate LO-AC scale} \\ 0 \text{ to } 14, 42, 140, 420, \\ 1400, 4200 \text{ volts} \end{array} \right.$

Overall Accuracy..... $\pm 5\%$ of full scale
Input Resistance and Capacitance

(With Direct Probe & Cable WG-218):

1.5, 5, 50, 150-V Ranges..... 0.83 meg. shunted by 70 μf

500-V Range..... 1.3 meg. shunted by 60 μf

1200-V Range..... 1.5 meg. shunted by 60 μf

Frequency Response:

With Direct Probe & Cable WG-218* $\left\{ \begin{array}{l} 30 \text{ cps to } 3 \text{ Mc} \square \\ 30 \text{ cps to } 500 \text{ kc} \Delta \\ 30 \text{ cps to } 270 \text{ kc} \circ \\ 30 \text{ cps to } 80 \text{ kc} \diamond \end{array} \right.$

With Crystal Probe WG-264* $\left\{ \begin{array}{l} \text{within } \pm 10\% \text{ from} \\ 50 \text{ kc to } 250 \text{ Mc} \end{array} \right.$

Pulse Response Capability..... See Fig. 7

Ohmmeter:

Ranges, Seven..... 0 to 1000 megohms

Meter Movement:

DC Current for Full-Scale Deflection..... 200 μa

Tube Complement:..... 2 RCA-6AL5, 1 RCA-12AU7

Power Supply:

Voltage Rating..... 105-125 volts

Frequency Rating..... 50/60 cps

Power Consumption (Approx.)..... 6 watts

Battery (1.5-volt cell)..... 1 RCA-VS036

Maximum Input Voltages: (For instruments with code numbers 350.)

DC Voltages with no ac voltage present:..... 1500 volts

AC Voltages with no dc voltage present:

RMS for Sine Waves..... 1200 volts

Peak-to-Peak for Sine Waves..... 3400 volts

Peak-to-Peak for Complex Waves..... 1400 volts

Combined AC and DC Voltages—

Sum of DC Voltage and AC Peak Voltage:

AC Component Measurements..... 1400 volts

DC Component Measurements..... 1500 volts

Maximum Input Voltages: (For instruments with all code numbers except 350.)

DC Voltages with no ac voltage present:..... 1500 volts

AC Voltages with no dc voltage present:

RMS for Sine Waves..... 1500 volts

Peak-to-Peak for Sine Waves..... 4200 volts

Peak-to-Peak for Complex Waves..... 2000 volts

Combined AC and DC Voltages—

Sum of DC Voltage and AC Peak Voltage..... 2000 volts

Mechanical

Overall Dimensions:

Height 7 $\frac{3}{8}$ inches

Width 5 $\frac{3}{4}$ inches

Depth 4 $\frac{1}{2}$ inches

Weight 5 $\frac{1}{2}$ pounds

Finish..... $\left\{ \begin{array}{l} \text{blue-gray hameroid case} \\ \text{satin aluminum panel} \end{array} \right.$

*For ac voltage ranges up to and including the 500-volt range (500 v. rms or 1400 v. p-p).

\square For source impedances of approximately 100 ohms or lower. Response is up about 10% at 3 Mc.

Δ For source impedances of approximately 1000 ohms or lower. Response is up about 10% at 500 kc.

\circ For source impedances of approximately 5000 ohms or lower. Response is down about 10% at 270 kc.

\diamond For source impedances of approximately 10000 ohms or lower. Response is down about 10% at 80 kc.

• Available on separate order.

Functions of Controls and Terminals

Function selector—Has two functions; turns the power off in "OFF" position, and permits choice of type of measurement to be made.

Range selector—Permits choice of range for the desired voltage or resistance measurements.

ZERO ADJ control—Used to position the meter pointer at either the left-hand "0" position or, when function selector is set to "+VOLTS", to the zero-center "—0+" position.

OHMS ADJ control—Used to position the meter pointer at the extreme right line on the "R" scale when the function selector is in "OHMS" position.

VOLTS AC DC terminal—Voltages to be measured are applied between this terminal and the GND terminal by means of the probes and cables specified under "Operation" below.

OHMS terminal—Resistances to be measured are connected between this terminal and the GND terminal.

GND terminal—is directly connected to the chassis of the instrument; serves as a common ground for the WV-97A and the chassis of the equipment under test as well as for associated test instruments.

Operation and Applications

Preliminary Adjustments:

To prepare the WV-97A for use, make the following connections and adjustments:

1. Connect the Direct Probe and Cable to the VOLTS AC DC terminal, the Ground Cable to the GND terminal, and the Ohms Cable to OHMS terminal.
2. Plug the power cord into an ac outlet supplying 105-125 volts at 50/60 cycles, and adjust the controls as indicated below:

- a. Turn the function selector to "+VOLTS" position, and allow several minutes for the instrument to warm up.
- b. Adjust the ZERO ADJ control to position the meter pointer at the left-hand "0".

NOTE: To check this adjustment, notice whether or not the position of the meter pointer changes when the function selector is switched to "-VOLTS". If the pointer position changes, readjust the mechanical zero control as described in the Maintenance Section.

- c. Turn the function selector to "OHMS" position. The pointer should deflect to approximately full scale.
- d. Rotate the OHMS ADJ control to position the pointer at the last line on the "R" (ohms) scale.
- e. Turn the function selector to "AC VOLTS" position. If the meter pointer does not read zero volts when the range selector is set on "1.5V", refer to steps 2, 3, 4 of "AC Calibration" and to the "Electrical Balance Check" in the Maintenance Section.

The instrument is now ready for use.

DC-Voltage Measurements:

CAUTION: See Maximum Input Voltages, under "Specifications".

The WG-217 DC Probe must be used with the WG-218 Direct Probe and Cable for all dc-voltage measurements.

The WV-97A has seven dc-voltage ranges: 0 to 1.5, 5, 15, 50, 150, 500, and 1500 volts. Although the meter is protected against burnout, it is good practice to make a trial measurement at a higher range setting than is expected because long-continued or repeated overload of the meter movement may eventually impair the accuracy of indication.

To measure dc voltages, proceed as outlined below:

1. Set the function selector to "+VOLTS" or to "-VOLTS", as required.
2. Connect the Ground Cable clip to ground or low side of source voltage.
CAUTION: See first paragraph of "Safety Precautions".
3. Set the range selector to a position considerably higher than the voltage to be measured.
4. Touch or connect the DC Probe to the high side of the source voltage.
5. Reset the range selector to a position which gives a suitable pointer deflection.
6. Read the dc voltage from the scale corresponding to the range-selector setting.

NOTE: Although the ground lead of the WV-97A must never be connected to a high-voltage point in a circuit, it is occasionally necessary to connect the ground lead to a "low-side" point which may be a few volts above ground. This "low-side" connection is permissible, but it should be remembered that the accuracy of the WV-97A may be impaired if an appreciable potential exists between GND terminal and the power-line ground.

Zero-Center Indication:

Zero-center indication is frequently useful because it allows observation of either positive or negative dc-voltage excursions without the necessity of resetting the function selector.

1. Set the function selector to "+VOLTS".
2. Rotate the ZERO ADJ control to position the pointer at the center "-0+".
3. Set the range selector to a position at least double the voltage to be measured.
4. After a test reading has been made, the range selector may be set to the lowest position which allows the pointer to remain on the scale.

Resistance Measurements:

The Ohms Cable is used in making all resistance measurements.

Before resistance measurements are made, the power should be removed from the equipment under test so that no voltages are present in the equipment.

1. Set the function selector to "OHMS" position.
2. Set the range selector to "R x 10" position.

3. Connect the Ohms Probe to the Ground Cable and adjust the ZERO ADJ control to position the pointer at the left-hand "0" if necessary.
4. Disconnect Ohms Probe from Ground Cable. Meter pointer will deflect approximately full scale. If meter pointer does not deflect to exactly full scale, use OHMS ADJ control to obtain full deflection.
5. Connect the clip of the Ground Cable to one terminal of the resistance to be measured.
6. Touch or connect the Ohms Probe to the other terminal of the resistance to be measured.
7. Reset the range switch to give a convenient deflection on the "R" (ohms) scale. See Ohms Adjustment section on page 15.
8. Multiply the reading on the "R" scale by the factor indicated at the range-selector setting.
CAUTION: Low-current, low-resistance devices, such as thermocouples and meter movements, may be damaged unless a range above "R x 10" is used because the WV-97A applies up to 1.5 volts across the resistance under measurement when the range selector is set at "R x 1" or "R x 10".




Figure 2. Circuit for measurement of resistance values above 1000 megohms.

When making resistance measurements, the Direct Probe of the WV-97A is always positive with respect to the Ground Cable. This arrangement facilitates the measurement of leakage resistance in components such as electrolytic capacitors where polarity must be observed.

Measurement of Resistance Values Above 1000 Megohms:

The leakage resistance of small mica and paper capacitors is usually above 1000 megohms. The circuit shown in Fig. 2 can be used to measure resistance values above 1000 megohms. An external dc voltage source between 20 and 500 volts is utilized to obtain a measurable pointer deflection. Make circuit connections as shown in Fig. 2 and proceed as follows:

1. Set Selector switch to "+VOLTS" and measure the voltage at point "B".
2. Measure the voltage at point "A".
3. Compute the unknown resistance from the following formula:

$$R_x \text{ (megohms)} = \frac{11 [(\text{Volts at "A"}) - (\text{Volts at "B"})]}{(\text{Volts at "B"})}$$

EXAMPLE:

An unknown resistance is to be determined with the circuit of Fig. 2. An external voltage of 500 volts is applied. The WV-97A measures 2.5 volts at "B", and 500 volts at "A". Then,

$$R_x = 11 (500 - 2.5) / 2.5 = 2200 \text{ megohms (approx.)}$$

AC Voltage Measurements:

CAUTION: See Maximum Input Voltages, Under "Specifications".

See discussion in Maintenance Section on Meter Response.

The WG-218 Direct Probe and Cable is used for ac-voltage measurements. (Remove the WG-217 DC Probe.)

1. Set the function selector at "AC VOLTS" position.
2. Adjust the ZERO ADJ control if necessary to position the meter pointer at the left-hand "0".
3. Set the range selector to a position considerably higher than the voltage to be measured.
4. Touch or connect the Direct Probe to the high side of the source voltage.




Figure 3. Typical voltage waveforms.

92CS-7545

5. Reset the range selector to a position which gives a suitable pointer deflection.
6. Read the dc voltage from the scale corresponding to the range-selector setting.

RMS scales are in black, with full-scale values of 1.5, 5, 15, 50, 150, 500, and 1500 volts. Peak-to-peak scales are in red. AC voltages of 1.5 rms volts, or 4 peak-to-peak volts, or less are read on the lowest meter scales; higher voltages are read on the two center scales. The instrument has a rated input for non-symmetrical waves of 1400 or 2000 peak-to-peak volts. However, sine waves and symmetrical complex waves can be measured to 3400 or 4200 volts peak-to-peak with somewhat reduced frequency response. See *Maximum Input Voltages* on page 6. In the case of sine waves, the instrument is conveniently calibrated to read directly both rms values and peak-to-peak values. This is practical because the relation of peak-to-peak values to rms values for any sine wave is a fixed ratio of 2.83 to 1. For example, with the range selector set at "15 V" and a sine wave of 10 rms volts applied to the instrument, the meter pointer




Figure 4. Details of WV-97A scales.

will rest at 10 on the rms black scale and at 28.3 on the associated peak-to-peak scale. Thus, the WV-97A reads both the rms and peak-to-peak values of sine waves simultaneously; as a peak-to-peak reading meter, the WV-97A is indispensable in trouble-shooting TV circuits. Typical TV voltage waveforms are shown in Fig. 5. Examples of some of the basic waveforms that can be measured with the WV-97A are shown in Fig. 6. When the WV-97A is used for ac measurements, certain precautions in interpreting the readings are necessary just as with all voltage-measuring instruments. Inaccurate readings may be obtained, if the impedance of the circuit under measurement is high, if the frequency of the voltage source is high, or if the voltage waveform consists of narrow pulses with a low repetition rate. The error of the readings increases with the ratio of the source impedance to the instrument impedance and varies with frequency (see "Electrical Specifications" on page 6 for information on the input resistance, input capacitance, and frequency response). Also, when narrow pulses with low repetition rates are measured, the capacitors in the peak-to-peak rectifier of the WV-97A have in-

sufficient time during the pulse to charge fully, and too long a period between pulses to retain the charge. The magnitude of the error caused by this effect is shown in Fig. 8, which holds for essentially rectangular pulses derived from a source with an internal impedance of 50 ohms or lower. For sources having higher internal impedances, the error will be correspondingly greater.




Figure 5. Typical TV voltage waveforms.




Figure 6. Voltage waveforms.

Special Applications

The WV-97A is generally useful in the maintenance and service of ac, dc, af, and pulsed electronic and electro-mechanical equipment. When used with the WG-264 Crystal-Diode Probe, it can be used to measure rf voltages between 50 kc and 250 Mc. The special applications discussed below will serve to illustrate the wide range of usefulness of the WV-97A.

Oscillator Grid-Bias Measurement. The negative dc voltage developed at the grid of an oscillator tube is always proportional to the amplitude of oscillation. The WV-97A has high input impedance and can be used to measure this bias voltage. Comparative readings should be taken on each band of a multi-band receiver, and the ganged tuning capacitor should be rotated through each band while the bias is measured.

AVC Voltage Measurements. The WV-97A can be used to measure avc voltage at the diode load resistor, along the avc bus, or at the grids of the controlled tubes.

Output Indication. The WV-97A is a very useful output indicator for alignment of radio and television receivers. The DC Probe is usually connected to the load resistor of the second detector in AM and TV receivers. In an FM receiver, the probe is connected to the limiter load resistor. The zero-center feature of the WV-97A is particularly useful in alignment of FM discriminators.

Bias-Cell Voltage Measurements. Bias-cell voltages can be accurately measured with the WV-97A.

Detection of Gassy Tubes. An occasional gassy tube may be encountered in electronic equipment. The presence of gas in an output tube or avc-controlled tube can lead to various circuit disturbances. Measurement of the grid bias in an RC-coupled circuit shows the presence of a gassy tube as a subnormal or positive value of bias. The same symptom can also be caused by a leaky coupling capacitor.

Insulation-Resistance Measurements. Current leakage through the insulating material of capacitors, coils, transformers, cables, and other components, can be measured with the WV-97A in terms of resistance. Values of leakage resistance above 1000 megohms can be measured with the circuit shown in Fig. 2.

DBM Measurements. The chart shown in Fig. 1 can be used to determine dbm values corresponding to rms ac-voltage values across a 600-ohm resistive load. A dbm value is defined as the number of decibels above

or below a reference level of 1 milliwatt in 600 ohms at 1000 cycles. Accordingly, 0 dbm indicates a power level of 1 milliwatt; 10 dbm, 10 milliwatts; 20 dbm, 100 milliwatts; etc.




Figure 7. Pulse response capability of WV-97A.

Because dbm are defined with respect to a 600-ohm load, power levels correspond to voltage values. Therefore, dbm can be measured in terms of rms voltages across a 600-ohm resistive load. For example, 0.775 rms volt indicates 0 dbm; 7.75 rms volts indicates 20 dbm, etc. While these measurements must be made with a sine waveform to avoid waveform error, any frequency can be used which is within the range of the WV-97A. The correlation between decibels and ear response is maximum at 1000 cycles.

The chart shown in Fig. 1 provides rapid conversion of rms voltages to corresponding dbm values. Associated power levels can be read along the top of the chart. This chart is applicable to resistive loads other than 600 ohms when a suitable term is added algebraically to the dbm values appearing along the axis of ordinates.

For rms volts measured across a 500-ohm resistive load, add 0.792 dbm algebraically to values read from chart. For rms volts measured across other resistive loads, use formula:

$$\Delta \text{DBM} = 10 \log \frac{600}{R}$$

where R is the load in ohms, and ΔDBM is the corresponding increment to be added algebraically to the dbm value read from the chart. If $R > 600$, ΔDBM is negative.

The following table lists the DBM values for most of the load resistances encountered in amplifier work.

Resistive Load at 1000 cps	DBM*
600	0
500	+ 0.8
300	+ 3.0
250	+ 3.8
150	+ 6.0

Resistive Load at 1000 cps	DBM*
50	+10.8
15	+16.0
8	+18.8
3.2	+22.7

* DBM is the increment to be added algebraically to the dbm value read from the chart on page 4, figure 1.

Accessories

Available on Separate Order

The WG-264 Crystal Diode Probe consists of a germanium rectifier and an RC network housed in a probe which slips onto the WG-218 (Direct Probe and Cable). The maximum voltage rating of the instrument with the WG-264 is 20 volts rms, in the presence of dc voltages up to 250 volts. The frequency range is 50 kc to 250 Mc. Voltage readings are made on the dc scales in terms of rms volts for sine waves.

The WG-289 High-Voltage Probe in combination with a multiplier resistor (WG-206) extends the dc rating of the WV-97A to a maximum of 50,000 volts for use in high-impedance circuits. DC scales are multiplied by a factor of 100, providing 6 full-scale positions of 150, 500, 1500, 5000, 15,000 and 50,000 volts. When the probe is used, the total input resistance is increased to 1100 megohms, a valuable feature for making measurements in phototube circuits, TV high-voltage




Figure 8. Accessories available on separate order for use with WV-97A.

power supplies, and other high-impedance circuits having inherently poor regulation.

Maintenance

See "Safety Precautions," page 2.

General

The WV-97A is manufactured and tested under strict engineering supervision. However, after long continued use the instrument may require tube replacement, or other attention.

Locations of calibration controls are shown in Fig. 10. A schematic diagram of the WV-97A is shown in Fig. 9.

The performance of the Senior VoltOhmyst is dependent upon the quality and tolerances of its circuit components. If it becomes necessary to replace a component part, the stock number can be found in the Replacement Parts List, page 13. Only RCA replacement parts, or parts which have equivalent specifications, should be used.

Zero Setting of Pointer

Mechanical Adjustment

The pointer should rest at "0" when the power is shut off. If the pointer should come to rest at a deflected position when the selector switch is turned to "OFF", adjust the pointer position mechanically, as follows:

1. Unscrew the moisture-proof meter-adjustment screw plug
2. Insert a scriber or similar tool to engage the zero-adjustment lever, and move the lever laterally as required to bring the pointer to "0".

Caution: Extreme care must be taken to prevent insertion of the tool to a depth which will injure the pointer spring. The meter warranty does not cover such damage.

3. Replace the meter-adjustment screw plug.




Figure 9A. Schematic diagram for instruments with code number 350.




Figure 98. Schematic diagram for all instruments except those with code number 350.

Replacement Parts List

When ordering Replacement Parts, please state Serial Number and Code Number of Instrument.

Symbol No.	Description	Stock No.	Symbol No.	Description	Stock No.
	Capacitors, Fixed and Variable				
C 1#	Paper tubular, 0.1 μ f \pm 20%, 1000 volts.....	59535	R 24	Fixed composition, 1800 ohms \pm 5%, 1/2 watt.....	—
C 1*	Paper tubular, 0.1 μ f \pm 20%, 600 volts.....	73557	R 25	Carbon film type, 7.0 meg., \pm 1%, 1 watt.....	59538
C 2	Ceramic trimmer, 5-20 μ f, \pm 20%	64689	R 26	Carbon film type, 2 meg., \pm 1%, 1/2 watt.....	59540
C 3, 4#	Molded paper, 0.1 μ f \pm 20%, 400 volts.....	73551	R 27	Carbon film type, 700,000 ohms \pm 1%, 1/2 watt.....	59541
C 3, 4*	Paper tubular, 0.047 μ f \pm 20%, 400 volts.....	73553	R 28	Carbon film type, 200,000 ohms \pm 1%, 1/2 watt.....	56733
C 5, 6	Fixed mica, 3300 μ f \pm 20%, 600 volts.....	39664	R 29	Carbon film type, 70,000 ohms \pm 1%, 1/2 watt.....	59542
C 7	Dry electrolytic, 10 μ f \pm 20%, 150 volts.....	56234	R 30	Carbon film type, 20,000 ohms \pm 1%, 1/2 watt.....	59177
	Jacks and Connectors		R 31	Carbon film type, 10,000 ohms \pm 1%, 1/2 watt.....	55665
J 1	Connector, male, single contact, chassis mounting.....	54695	R 32	Variable carbon, 2 meg., \pm 20%, 1/2 watt.....	59534
J 2, 3#	Jack, single contact input jack.....	55239	R 33	Fixed composition, 6.8 meg., \pm 5%, 1/2 watt.....	31071
J 2, 3*	Jack, single contact input jack.....	93858	R 34	Fixed composition, 1.8 meg., \pm 5%, 1/2 watt.....	11769
	Resistors, Fixed and Variable		R 35	Fixed composition, 680,000 ohms \pm 5%, 1/2 watt.....	30562
R 1	Carbon film type, 900,000 ohms \pm 1%, 1 watt.....	59536	R 36	Fixed composition, 180,000 ohms \pm 5%, 1/2 watt.....	11959
R 2#	Carbon film type, 320,000 ohms \pm 1%, 1/2 watt.....	59544	R 37	Fixed composition, 100,000 ohms \pm 5%, 1/2 watt.....	3252
R 2*	Carbon film type, 325,000 ohms \pm 1%, 1/2 watt.....	93872	R 38	Same as R 18.....	—
R 3	Carbon film type, 150,000 ohms \pm 1%, 1/2 watt.....	56483	R 39	Fixed composition, 1.0 meg., \pm 5%, 1/2 watt.....	30652
R 4#	Carbon film type, 21.0 meg., \pm 1%, 1 watt.....	59537		Transformers	
R 4*	Carbon film type, 20.3 meg., \pm 1%, 1 watt.....	93871	T 1	Power pri., 117 volts, 50 60 cycles..	59527
R 5	Fixed wire wound, 9.7 ohms \pm 1%, 1/2 watt.....	59545		Miscellaneous	
R 6	Carbon film type, 9 meg., \pm 1%, 1 watt.....	59539		Cable, ohms black with probe....	51960
R 7	Carbon film type, 900,000 ohms \pm 1%, 1/2 watt.....	55661		Cable, ground lead black, with alligator clip.....	48996
R 8	Carbon film type, 90,000 ohms \pm 1%, 1/2 watt.....	56725		Case, meter.....	93811
R 9	Carbon film type, 9000 ohms \pm 1%, 1/2 watt.....	56723		Clip, alligator to fit 1/8" diameter pin	59410
R 10	Carbon film type, 900 ohms \pm 1%, 1/2 watt.....	54197		Clip, alligator for ground lead.....	35262
R 11	Carbon film type, 90 ohms \pm 1%, 1/2 watt.....	55859		Connector, for direct cable, double contact, male.....	59528
R 12	Variable carbon, 15,000 ohms \pm 20%, 1/2 watt.....	59532		Connector, cable, female 2 contact..	59547
R 13, 14	Variable carbon, 10,000 ohms \pm 20%, 1/4 watt.....	59533		Handle, carrying case.....	44091
R 15	Fixed composition, 3.3 meg., \pm 10%, 1/2 watt.....	31417		Holder, battery clamp.....	59524
R 16	Fixed composition, 39,000 ohms \pm 5%, 1/2 watt.....	30147		Insert, brass, for dc probe.....	59548
R 17	Same as R 12.....	—		Knob, control, blue, large.....	59543
R 18, 38	Fixed composition, 33,000 ohms \pm 5%, 1/2 watt.....	30685		Knob, control, blue, small.....	53689
R 19	Fixed composition, 1800 ohms \pm 5%, 1/2 watt.....	30930	S 1#	Meter, dc, 0 to 200 μ amp.....	59523
R 20	Fixed composition, 47,000 ohms \pm 5%, 1/2 watt.....	30787	S 1*	Plug, pin, black, for ground lead....	47089
R 21	Same as R 19.....	—	S 2#	Shell, black, for dc probe.....	59549
R 22	Fixed composition, 56,000 ohms \pm 5%, 1/2 watt.....	30650	S 2*	Shell, for cable connector, female, black.....	59529
R 23	Fixed composition, 47,000 ohms \pm 5%, 1/2 watt.....	—		Sleeve, for cable connector, black....	59530
				Shield for dc probe.....	59550
				Socket, tube, miniature, 7 pin.....	56382
				Socket, tube, miniature, 9 pin.....	59531
				Switch, rotary, range 7 position, 3 section, 5 circuit.....	59525
				Switch, rotary, range of position, 3 section, 5 circuit.....	93868
				Switch, rotary, selector, 5 position, 2 section, 4 circuit.....	59526
				Switch, rotary, selector, 5 position, 3 section, 4 circuit.....	93867
				Tip, for dc probe.....	59551

* For all instruments except those with code 350.

For instruments with code number 350.

Electrical Balance Check

1. Set the function selector to "+VOLTS".
2. By rotating the ZERO ADJ control, it should be possible to set the meter pointer at either zero or 60% of full deflection on any range.
3. Set the function selector to "-VOLTS".
4. By rotating the ZERO ADJ control, it should be possible to set the meter pointer at either zero or 10% of full deflection on any range.
5. If steps 2 and 4 above cannot be accomplished, the two triode units of the 12AU7 tubes are not in close enough balance for this application and the tube should be replaced. Refer to Tube Replacement section.

Meter Response

For those instruments with code No. 350, a time delay will be observed after ac measurements are made. This will ensue from the instant that the leads are removed from the voltage source being measured to the instant the meter pointer returns to "0". This delay is normal and is caused by circuit constants so chosen that recurrent pulses with low repetition rates may be accurately measured. In applications where it is desirable to measure recurrent pulses with relatively high-repetition rates, the time required for the meter needle to return to "0" may be decreased by reducing the value of capacitors C-3 and C-4 from 0.1 μ f to 0.47 μ f.

Calibration

If it becomes necessary to recalibrate the WV-97A, proceed as follows to restore the initial accuracy of the instrument:

Note: The accuracy of calibration cannot exceed the accuracy of the voltage standards which are used.

DC Calibration

1. Check the mechanical zero position of the pointer. If necessary, zero the pointer as described above.
2. Turn selector switch to "+VOLTS" and allow the WV-97A to warm up for at least 30 minutes.
3. Check line voltage. The WV-97A should be calibrated at 117 volts, 60 cycles.
4. Rotate the ZERO ADJ control (R17) to bring the pointer exactly to "0". (This control is not used again in the calibration procedure.)
5. Set range selector to the "50 V" position.
6. Connect the black-lead clip to the negative terminal of an accurate 50-volt dc source. Connect the DC Probe to the positive terminal of the source voltage.
7. Adjust the "+DC CAL" control (R13) to bring the pointer exactly to the 50-volt point on the scale. (Refer to Fig. 10)
8. Reverse the test-lead connections to the voltage source.
9. Set function selector to the "-VOLTS" position.
10. Adjust the "-DC CAL" control (R14) to bring the pointer exactly to the 50-volt point on the scale.
11. Check the other dc ranges from other dc sources which provide full-scale deflection and which have accurately known voltages.

AC Calibration Check

If ac calibration has not been preceded by dc calibration, first follow the four initial steps under DC Calibration. Then proceed as follows:

1. Remove WG-217 DC Probe from WG-218 Direct Probe and Cable.
2. Set function selector to "AC VOLTS".
3. Set range selector to "1.5 VOLTS".
4. Adjust the AC ZERO screwdriver control at the rear of the instrument for a zero meter reading. The probe (WG-218) tip should be connected to the ground clip for this adjustment. If a zero meter reading cannot be obtained, interchange the two 6AL5 tubes. If the pointer cannot be brought to zero after the interchange of tubes, replace 6AL5 tubes. Refer to Tube Replacement section.

5. Apply 50 volts, 60 cps between the ground lead and the tip of the WG-218 Direct Probe and Cable. The meter reading should read within the accuracy stated in the Specifications section of this manual. If it does not, check values of circuit components.

AC Compensation Adjustment

1. Remove WG-217 DC Probe from WG-218 Direct Probe and Cable.
2. Set function selector to "AC VOLTS".
3. Set meter pointer at zero.
4. Set the function selector on the 500-volt range and apply an accurate 200-volt, 100-kc sine-wave signal between the ground lead and tip of the WG-218 Direct Probe and Cable. Adjust C-2 located at the rear of the instrument (see Fig. 10) for a 200-volt meter reading.

Ohms Adjustment

In order to obtain exactly full-scale deflection of the meter when switching the range selector from a low range position to the "RX1 MEG" position, it may be necessary to readjust the OHMS ADJ control. The necessity for this readjustment can be eliminated by using a battery in good condition and by installing a 12AU7 tube which has a low value of grid current.




Figure 10. Calibration control locations.

Tube Replacement

When replacing tubes in the WV-97A, it may be necessary to select tubes from a group of several tubes in order to find one that will operate satisfactorily. This selection may sometimes be avoided by operating the instrument with the new tubes for a continuous period of 12 to 36 hours before attempting final calibration.

Battery Testing and Replacement

Caution: Do not allow exhausted cells to remain inside the case of the WV-97A. Chemicals from deteriorated cells may damage the instrument.

The battery should be tested frequently to insure accuracy of resistance measurements. To test battery, proceed as follows:

1. Set Function selector to "OHMS".
2. Set Range selector to "RXI" scale.
3. Rotate OHMS ADJ control to bring pointer to full scale.
4. Short-circuit Ohms Probe and Ground Clip for about ten seconds.
5. Open the short-circuit and immediately observe the scale indication. An appreciable deviation from full-scale indication reveals weak cells which should be replaced.